

Varitrak K SideBand Assembly Assistance

Proper Dis-Connection and Re-Connection of the Varitrak K sideband.

<p>DIS-CONNECTION 1</p>	<p>DIS-CONNECTION 2</p>	<p>DIS-CONNECTION 3</p>
<p>Take section of Varitrak K and tip up on one end roughly 15° off solid surface.</p>	<p>Strike sideband at hinge connection one link above desired last link (example here, 4 links are needed).</p>	<p>Once sideband is struck, let the sideband naturally drop to surface separated.</p>
<p>RE-CONNECTION 1</p>	<p>RE-CONNECTION 2</p>	<p>RE-CONNECTION 3</p>
<p>Correctly align two sections of sideband, the last link from each, above each other.</p>	<p>Drop in while adjusting upper section to lower section. They will properly "seat" into each other.</p>	<p>With both <u>sections lying on flat surface</u>, smartly strike the top link at the hinge connection point.</p>
<p>RE-CONNECTION 4</p>	<p>RE-CONNECTION 3a</p>	<p>RE-CONNECTION 4a</p>
<p>Once struck, the top link should have snapped into place. The bottom link connection pin will be properly seated into top link.</p>	<p>If a flat surface isn't available, use a quick-grip clamp. Again, align links so they nest correctly (2 above). Align clamp similarly.</p>	<p>Squeeze/pump quick-grip clamps until links has snapped into the other links nest correctly. Repeat as required.</p>